Quick Installation Guide

English | 繁中 | 简中 | 日本語 | Français | Español | Deutsch | Português | Italiano | Türkçe | Polski | Русский

IZ7151 Network Camera

18x Zoom Progressive Scan CCD



VIVOTEK

Warning Before Install


- **Power off the Network Camera as soon as it is found smoking or smelt unusual.**

  Contact your distributor when such cases happen.


- **Keep the Network Camera away from water. If the Network Camera is wet, power off immediately.**

  Contact your distributor when such cases happen.


- **Do not place the Network Camera around the heat sources, such as television or oven.**




- **Refer to your user's manual for the operating temperature.**




- **Keep the Network Camera away from direct sunlight.**




- **Do not place the Network Camera in high humid environments.**




Do not place the Network Camera on unsteady surfaces.




Do not touch the Network Camera when it's lightening.




Do not disassemble the Network Camera.



Do not drop the Network Camera.




Do not insert any object into the Network Camera, such as needles.




1 Check Package Contents


- **IZ7151**




- **Power adapter**



- **Camera stand**



- **Screws and top mounting stand**




- **Quick installation guide**



- **Software CD**




- **Warranty card**




2 Physical Description

Front panel




Back panel



3 Hardware Installation

Mounting the camera


1. Attach the top mounting stand to the camera using the supplied screws.
2. Fasten the camera stand to the wall / ceiling.
3. Secure the camera to the camera stand.
4. Position the camera with the lens facing the desired monitoring area.



4 Network Deployment

General Connection (without PoE)


1. Connect the camera to a switch via Ethernet cable.
2. Connect the supplied power cable from the camera to a power outlet.



Power over Ethernet (PoE)


When using a PoE-enabled switch

The camera is PoE-compliant, allowing transmission of power and data via single Ethernet cable. See the following illustration to connect the camera to a PoE-enabled switch via Ethernet cable.




When using a non-PoE switch


Use a PoE power injector (optional) to connect between the camera and a non-PoE switch.




5 Assigning IP Address

1. Install the "Installation Wizard 2" under the Software Utility directory from software CD.
2. The program will conduct analyses on your network environment. After your network is analyzed, please click on the "Next" button to continue the program.






3. The program will search the VIVOTEK Video Receivers, Video Servers or Network Cameras on the same LAN.
4. After searching, the main installer window will pop up. Click on the MAC that matches the one labeled on the bottom of your device to connect the Internet Explorer to the Network Camera.



6 Retrieving Images



For further setup, please refer to user's manual on the software CD.

VIVOTEK
WWW.VIVOTEK.COM

P/N:625004600G

6F, No.192, Lien-Cheng Rd., Chung-Ho, Taipei County, Taiwan | **T:** +886 2 82455282 | **F:** +886 2 82455532 | **E:** sales@vivotek.com